




Noise-canceling microphone reduces background sounds.

Notes: If you hear no sound after connecting to your PC, open the **Sounds and Multimedia** (or **Sounds and Audio Devices**) control panel and select the **Audio** tab, then select **USB Audio Device** for input.

Adjustable Neck Boom

Press to mute. The LED lights red when muted. Press again to unmute; the LED lights blue.



Connect to your PC

RF Emissions Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult your local *RadioShack* store or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your microphone. Changes or modifications not expressly approved by *RadioShack* may cause interference and void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Thank you for purchasing your PC Desktop Microphone. Please read this user's guide before installing, setting up and using your new microphone.

System Requirements

- Windows® 98SE
- Windows Me
- Windows 2000
- Windows XP
- Windows Vista™
- Macintosh® 10.3.9
- Available USB Port

What's Included

- Microphone
- User's Guide

Specifications

Power supply	USB port DC 5V
PC Interface	USB 2.0 / USB 1.1
Frequency response.....	100 - 10000 Hz
Impedance	less than 2200 ohms
Sensitivity	- 60 + / 4 dB
Length of cable	about 8 feet

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.

Limited 90-day Warranty

This product is warranted by *RadioShack* against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from *RadioShack* company-owned stores and authorized *RadioShack* franchisees and dealers. For complete warranty details and exclusions, check with your local *RadioShack* store.

RadioShack Customer Relations
300 RadioShack Circle
Fort Worth, TX 76102

04/04

www.radioshack.com